

Οδηγίες χρήσης:

(GR) Διαβάστε τις οδηγίες πριν την πρώτη χρήση & φυλάξτε τις για μελλοντική αναφορά. Κανόνες ασφαλείας:

- Η συσκευή λειτουργεί πανεύκολα με το πάτημα ενός κουμπιού.
- Μη βυθίζετε το σώμα της συσκευής ή το καλώδιο σε νερό ή άλλο υγρό.
- Μην αφήνετε τα παιδιά να παίζουν με τη συσκευή.
- Η συσκευή δεν πρέπει να χρησιμοποιείται από άτομα με ειδικές ανάγκες (σωματικές ή διανοητικές), παιδιά ή άτομα που δε διαθέτουν την απαιτούμενη γνώση & εμπειρία για τη χρήση της συσκευής, χωρίς την επιτήρηση κάποιου που γνωρίζει τον τρόπο λειτουργίας της συσκευής και θα είναι υπεύθυνος για την ασφάλειά τους.
- Μην αγγίζετε κινούμενα μέρη της συσκευής ενώ λειτουργεί.
- Μη χρησιμοποιείτε τη συσκευή σε εξωτερικούς χώρους.
- Ελέγξτε αν η ηλεκτρική τάση της συσκευής σας αντιστοιχεί στην τάση της ηλεκτρικής εγκατάστασης. Εάν όχι, μη θέσετε σε λειτουργία τη συσκευή κι επικοινωνήστε με ένα εξουσιοδοτημένο κέντρο επισκευών ΜΠΕΝΡΟΥΜΠΗ.
- Μη χρησιμοποιείτε τη συσκευή εάν το εξάρτημα ανάμειξης είναι κατεστραμμένο, εάν έχει κατεστραμμένο καλώδιο ή οποιαδήποτε άλλη βλάβη ή δυσλειτουργία. Επιστρέψτε τη σε ένα εξουσιοδοτημένο κέντρο επισκευών ΜΠΕΝΡΟΥΜΠΗ για επιδιόρθωση ή αντικατάσταση.
- Αποσυνδέετε τη συσκευή από την πρίζα όταν δεν τη χρησιμοποιείτε και πριν την καθαρίσετε.
- Μην προσπαθείτε να επισκευάσετε μόνοι σας τη συσκευή.
- Μην υπερβαίνετε το 1' συνεχούς λειτουργίας. Κλείστε τη συσκευή για τουλάχιστον 1' & ξαναθέστε τη σε λειτουργία
- Η συσκευή προορίζεται μόνο για οικιακή χρήση.
- Μη χρησιμοποιείτε τη συσκευή για οποιοδήποτε λόγο εκτός από αυτόν για τον οποίο προορίζεται.
- Καθαρισμός: Λειτουργήστε τη συσκευή σε ένα ποτήρι καθαρό νερό, βγάλτε το φιλ από την πρίζα & σκουπίστε τον άξονα με ένα πανί. Σκουπίστε με ένα μαλακό νωπό πανί το σώμα της συσκευής & αφήστε το να στεγνώσει.

(EN) Please read these instructions before first use & keep them for future reference.

Safety instructions:

- The appliance operated very easily at the touch of a button.
- Do not immerse the body of the appliance or the cable into water or other liquids.
- Do not let children play with the appliance.
- This appliance is not intended for use by people (including children) with reduced physical, sensory or mental capabilities, or or lack of knowledge and experience unless they have been given supervision and instructions concerning use of the appliance by a person responsible for their safety.
- Do not touch the moving parts of the appliance while in operation.
- Do not use this appliance outdoors.

- Check that the voltage rating of the appliance corresponds to the voltage of the electrical installation. If not, do not operate the appliance and contact an authorized BENRUBI service center.
- Do not use the appliance with a damaged axle, cord or plug, in case that the appliance malfunctions or has been damaged in any manner. Return the appliance to the nearest authorized BENRUBI service facility for repair or replacement.
- Unplug the appliance when not in use and before cleaning.
- Do not attempt to fix the appliance by yourself.
- Do not exceed 1' continuous operation. Switch the appliance off for at least 1' & then use it again.
- The appliance is intended for domestic use only.
- Do not use the appliance for other than the intended use.
- Cleaning: Operate the appliance in a glass of clean water, unplug it and wipe the axle with a cloth. Clean the body of the appliance with a soft, damp cloth & let it dry.