

GR

## Ανοξειδωτα σκεύη Cosmopolitan

- Υψηλής ποιότητας ανοξειδωτο ασάλι.
- Ανοξειδωτο καπάκι με σύστημα στραγγίσματος.
- Ειδικά ενισχυμένος πάτος τύπου “capsule” για ταχύτερη συσσώρευση και ομοιόμορφη κατανομή της θερμότητας.
- Κατάλληλα για εστίες ηλεκτρικές, κεραμικές, γκαζιού και επαγωγικές.
- Συσκευασία σε κουτί δώρου.

### Η Σειρά Περιλαμβάνει:

- Χύτρα με καπάκι 20εκ
- Χύτρα με καπάκι 24εκ
- Χύτρα με καπάκι 26εκ
- Χύτρα με καπάκι 28εκ
- Κατσαρολάκι γάλακτος με καπάκι 18εκ
- Σωτέζα 28εκ με καπάκι

### Πριν την Πρώτη Χρήση

#### • Αφαιρέστε τη συσκευασία και τα αυτοκόλλητα.

- Πλύνετε το σκεύος με ζεστό νερό και σαπούνι. Ξεπλύνετε και στεγνώστε καλά με μαλακό πανί ή χαρτί κουζίνας.

### Οδηγίες Χρήσης

• Χρησιμοποιείτε χαμηλή ή μέτρια θερμοκρασία για καλύτερη απόδοση του σκεύους. Η υψηλή θερμοκρασία μπορεί να προκαλέσει βλάβες οι οποίες δεν καλύπτονται από την εγγύηση.

- Μην αφήνετε το σκεύος στη φωτιά μέχρι να εξατμιστεί το περιεχόμενο και μην το αφήνετε άδειο σε ζεστό μάτι ή φλόγα αερίου.
- Πριν τη τοποθέτηση τροφίμων, τα οποία έχουν την τάση να κολλάνε (όπως γάλα), ξεπλύνετε το σκεύος με νερό.
- Μαγειρεύετε σε εστία με μέγεθος ίδιο ή μικρότερο από εκείνο της βάσης του σκεύους.
- Αφήστε το σκεύος να κρυώσει πριν τον καθαρισμό για να αποφύγετε το σκέβρωμα. Αποφύγετε οποιεσδήποτε ακραίες αλλαγές θερμοκρασίας.
- Μην αφήνετε το λίπος ή το λάδι να ζεσταίνεται τόσο ώστε να καπνίζει, να καίει ή να γίνεται μαύρο.
- Μην γεμίζετε το σκεύος περισσότερο από τα 2/3 της χωρητικότητάς του, ώστε να αποφεύγετε το πιτσίλισμα.
- Μην αποθηκεύετε στο σκεύος όξινα, αλμυρά ή λιπαρά τρόφιμα πριν ή μετά από το μαγείρεμα.

- Μη χρησιμοποιείτε μεταλλικά σφουγγάρια, σύρμα ή σκληρά καθαριστικά.
- Μη βάζετε ποτέ κρύο νερό σε ζεστό σκεύος. Μη βυθίζετε το ζεστό σκεύος σε κρύο νερό.
- Το σκεύος είναι κατάλληλο για πλύσιμο στο πλυντήριο πιάτων

## Εγγύηση

• Η εταιρία ΜΠΕΝΡΟΥΜΠΗ εγγυάται τα προϊόντα της για οποιαδήποτε ελάττωμα κατασκευής ή υλικών για πέντε (5) έτη από την ημερομηνία αγοράς ή παράδοσης με την προσκόμιση της απόδειξης αγοράς. Εάν το προϊόν που έχετε αγοράσει, παρουσιάσει ελάττωμα κατασκευής ή υλικών, απευθυνθείτε στο κατάστημα αγοράς ή σε εξουσιοδοτημένο Κέντρο Service ΜΠΕΝΡΟΥΜΠΗ. Για την ενημέρωσή σας σχετικά με το πλησιέστερο εξουσιοδοτημένο Κέντρο Service ΜΠΕΝΡΟΥΜΠΗ, επισκεφθείτε τη ιστοσελίδα μας [www.benrubi.gr](http://www.benrubi.gr).

• Η εγγύηση δεν καλύπτει ελαττώματα που θα προκύψουν από φυσιολογική φθορά, σπάσιμο, λανθασμένη συντήρηση του προϊόντος, κακό χειρισμό, μη εφαρμογή των οδηγιών χρήσης, κόλλημα φαγητού.

Επίσης, η εγγύηση δεν καλύπτει τα παρακάτω ενδεικτικά αναφερόμενα:

- Σημάδια, στάμπες, αποχρωματισμό ή γρατζουνιές
  - Χτυπήματα από πέσιμο του σκεύους
  - Υπερθέρμανση (υπερβολική έκθεση σε φλόγα ενώ είναι άδειο)
  - Βλάβη από θερμικό σοκ (απότομη αλλαγή θερμοκρασίας).
  - Επαγγελματική χρήση
  - Ζημιά σε γυάλινη επιφάνεια του προϊόντος
- Η ΜΠΕΝΡΟΥΜΠΗ εγγυάται ότι η ανοξειδωτή επιφάνεια είναι σύμφωνη με τους κανονισμούς που ισχύουν για τα υλικά που έρχονται σε επαφή με τα τρόφιμα.

### **ΓΙΑ ΠΕΡΙΣΣΟΤΕΡΕΣ ΠΛΗΡΟΦΟΡΙΕΣ:**

#### **Χ. ΜΠΕΝΡΟΥΜΠΗ & ΥΙΟΣ Α.Ε.**

Αγ. Θωμά 27, 15124, Μαρούσι – Αθήνα

Τηλ.: 210 6156400

Fax: 210 6199316

e-mail: [benrubi-sda@benrubi.gr](mailto:benrubi-sda@benrubi.gr)



EN

**Stainless Steel cookware Cosmopolitan**

- High quality stainless steel.
- Stainless steel lid with draining system.
- Specially fortified “capsule” bottom for fast and even heat distribution.
- Suitable for electric, ceramic, gas, and induction hobs.
- Gift box packaging.

**Cosmopolitan Cookware Include:**

- Casserole with lid 20cm
- Casserole with lid 24cm
- Casserole with lid 26cm
- Casserole with lid 28cm
- Saucepan with lid 18cm
- Deep frying pan with lid 28cm

**Before the First Use**

- Remove all packaging and stickers.
- Wash cookware in warm soapy water. Rinse and dry thoroughly using a soft cloth or paper towel.

**Use of Cookware**

- Use low or medium heat for the best cookware performance. High heat may damage your cookware and this type of damage is not covered under the guarantee.
- Do not leave the cookware boil dry or empty on a heated hob or gas flame.
- When using the cookware, make sure that the diameter of the hob is less or equal to the diameter of the bottom of the pot.
- Let the cookware cool before cleaning to prevent warping. Avoid any extreme temperature changes.
- Spots may be caused to the internal surface of the cookware due to overheating or thermal shock. This is not a product defect.
- Never heat fat or oil to the extent it smokes, burns or turns black.
- Do not fill the cookware more than the 2/3 of its capacity in order to avoid splashing.
- Do not use the cookware to store acidic, salty or fatty foods before or after cooking.
- Do not use metal sponges, wire or abrasive cleaners.
- Never put cold water into hot pan. Do not immerse the hot pan in cold water.

## Care and Cleaning

- **If the food “burns” into the cookware, fill it with hot water and dishwashing liquid and let it soak for about an hour. Then wash with a soft sponge.**
- Wash after use with hot water, liquid detergent and sponge. Rinse and dry thoroughly before next use or storage.
- The product is dishwasher safe.

## Guarantee & Customer Service

• BENRUBI Company guarantees its products for any manufacturing defect or defective materials for a period of five (5) years from the date of purchase or delivery by presenting purchase receipt. If your product malfunctions or you find any defects, please revert to the retail location you have purchased it from or contact an authorized BENRUBI Service Centre.

To find the nearest authorized BENRUBI Service Centre, visit our website [www.benrubi.gr](http://www.benrubi.gr).

- The warranty does not cover damages resulting from normal wear, breakage, improper maintenance of the product, mishandling, failure to implement the instructions, food sticking. Also, the warranty does not cover the following indicative factors:
- Stains, discoloration or scratches.
- If the products is knocked or dropped.
- Damage from thermal shock (sudden temperature change).
- Professional use.
- Any glass or porcelain ware in the product.

BENRUBI guarantees that the stainless steel surface is in accordance with the regulations applicable to materials that come into contact with food.

*FOR MORE INFORMATION CONTACT:*

**H. BENRUBI & FILS SA**

27 Aghiou Thoma str, GR15124

Maroussi – Athens

Tel.: 210 6156400, Fax: 210 6199316

e-mail: [benrubi-sda@benrubi.gr](mailto:benrubi-sda@benrubi.gr)

